VT-8001说明书　2024 11-25wj 对折页成品尺寸：67.5X100mm

67.5mm　67.5mm

100mm

SYMBOL

CE

This item is made in conformity with CE

DISPOSAL

The device (including its removable parts and accessories) must not be disposed of together with municipal waste at the end of its life, but in compliance with European Directive 2012/19/EC. Since it must be handled separately from household waste, either carry it to a separately-collected waste disposal centre for electrical and electronic appliances or give it back to the retailer on purchasing a new device with the same purpose. Any infringement will be severely prosecuted.
The built-in rechargeable battery contains substances that may pollute the environment. Always remove the battery before you discard and hand in the appliance at an official collection point. Dispose of the battery at an official collection point for batteries
First unplug the product and let the motor run until the battery is completely empty.
Remove both side panels from the appliance with a screwdriver.
Lift the power unit out of the appliance.
Specifications and designs are based on the latest information available at the time of printing and subject to change without notice.

VTU®
PROFESSIONAL
HAIR TRIMMER
VT-8011



COMPONENTS OF HAIR TRIMMER

1. Precision T-blade
2. ON/OFF Switch
3. USB Interface
4. Cutting guide combs(1/3/5/7mm)
5. USB charging cable
6. Oil
7. Cleaning brush

SAFETY WARNINGS

This appliance may be used by children of more than 8 years of age, persons with physical, sensory or mental capabilities or inexpert persons only if they have been previously trained in using it in a safe manner, and only if they have been informed of the dangers the product can cause.
Children may not play with the appliance. Children may not clean or carry out any maintenance on the appliance without adult supervision.

GENERAL SAFETY INSTRUCTIONS

It is advisable to save these instructions for a future use.
Always check the appliance before you use it. Do not use the appliance if it is damaged, as this may cause injury. Always replace a damaged part with one of the original type.
Do not open the appliance to replace the rechargeable battery.
This appliance is not washable. Never immerse the appliance in water and do not rinse it under the tap.
Never use compressed air, scouring pads, abrasive cleaning agents or aggressive liquids, such as petrol or acetone to clean the appliance.
IMPORTANT:This trimmer has a built-in rechargeable battery. Do not throw into fire, apply heat, or charge, use, or leave in a high temperature environment.
The appliance should not be used on animals.

OIL BOTTLE

Keep out of reach of children. Do not swallow. Do not apply to eyes. Dispose of properly when empty.

CUTTING GUIDES

By use of the 4 cutting guides provided, you can adjust the length of the trim up to a maximum of 7 mm (with the guide comb inserted).
The cutting lengths are as follows:with guide combs:1/3/5/7 mm. The length of the cut is shown on the guide comb.
IMPORTANT:The device must always be turned off when inserting or removing a cutting guide.

HOW TO USE

For uniform cutting, allow the trimmer to cut its way through the hair. Do not force it through at a faster rate.
Select the desired length on the adjustable comb or select the desired guide combs.
With 4 guide combs, start by combing the hair so it falls into its natural direction.
Place the largest guide comb onto your trimmer and start by trimming the sides from the bottom upwards. Hold the trimmer lightly against the hair, with teeth of the guide comb pointing up but flat against the head. Slowly lift the trimmer up and outward through the hair, cutting only a small amount at a time.Repeat around sides and back of head.

Detachable blade:

Push the top of the blade away from the trimmer with your thumb.
Insert the blade into the slot and press down the blade until the click sound.
Slide the clipping guards into the blade until it locks into place.
Push the rear of guard away from trimmer.

USB CHARGING

The hair clipper is completely handy to carry and can be charged anywhere with the USB cable.
Rechargeable-Comes with built-in battery, a full charging time 2 hours to offer around 60 minutes of running time.
Two charging methods:
Charging through USB cord(comes with the trimmer) Charge the device by connecting with the power bank or adapters(5V=1A), or computer.
Charger plug into the charging base connection.
Indicator light show blue when fully charged and using.
Indicator light show red when charging.

CLEANING AND MAINTENANCE

Before starting cleaning the appliance, always switch it off and unplug it.
Clean the unit with a damp and soft cloth.
Never use detergents and solvents to clean the appliance.
After having used the appliance remove the cutting guide and using the cleaning brush to clean the body of the device, in order to remove any hair from the cutting blade.
In order to grant a long and good performance to the appliance, it is advisable to clean and oil often the appliance.
For an easy cleaning it is possible to remove the cutting blades.
Open the cutting unit by pushing it backwards.
Remove hair from the cutting blade using the cleaning brush, reassemble the cutting unit, put 2 or 3 oil drops and allow the machine to run for several seconds so that the unit can lubricate properly.

TECHNICAL FEATURES

- ON/OFF switch
- Complete charging time:2 hours
- 60 minutes of continuous operation
- Power supply:5V=1A